



COLD LAY TARMAC EASI-REPAIR

FP McCann's Easi-Repair™ cold lay tarmac is a cost effective and efficient solution for temporary repairs to driveways, footpaths and a variety of other applications. Available in 20kg bags, tonne bags and in loose bulk, Easi-Repair™ is ready to use straight from the bag and does not require any further mixing. Produced in factory environment to maintain a consistent high level of quality.

GUIDANCE ON APPLICATION & USE

- Ensure the application area where Cold Lay Tarmac is to be laid is dry and compacted.
- Make sure that area has been swept and that any weeds have been removed.
- Use an ordinary rake, spade or trowel to spread the Cold Lay Tarmac to the required thickness.
- Use a roller to achieve good compaction or use a heavy, flat object for 'tamping' to achieve similar results
- Simplistic application, no previous experience is required
- No specialist tools or equipment are required
- Suitable for base or wearing course

**ALL PACKAGING IS
WEATHERPROOF AND
RECYCLABLE**



APPLICATIONS

- Footpath Patch
- Temporary Ramping
- Driveway Repair
- Temporary Road Crossing
- Pothole Repair
- Cycle Way Repair
- Emergency Repair
- Trip Prevention Repair

HINTS & TIPS

For potholes and patches deeper than 30mm deep

- Whenever repairing deeper pot-holes (greater than 30mm) lay the Easi-Repair™ in two stages. In the first stage compact the first layer before spreading the next layer. In the second stage, lay the Easi-Repair™ to the finished surface required level and then compact.

When not to use Easi-Repair™

- It is not recommended to use Easi-Repair™ in outside temperatures below 5°C or when the area to be worked is very wet.

Ground Preparation

- Before overlaying concrete or paving, spray or brush on a tack coat of bitumen emulsion (edging & jointing spray is recommended) at a rate of about 0.5litres/m² to help prolong the life of the repair, especially if prone to freeze/thaw conditions.

On completing your patch or ramp

- Do not place any heavy or sharp objects on the newly laid surface such as caravan legs, jockey wheels and other similar high loadings.
- Brush a little dry sand or dust over the surface after compaction to help prevent 'lifting up' of the fresh material as it sets. This is not essential but may be helpful, especially on warmer days.



SALES & TECHNICAL SUPPORT

Should you require additional information on this product, please contact our sales team on:

Telephone 028 79642 558 or
Email sales@fpmccann.co.uk

Additional information can be obtained from
fpmccann.co.uk/bagged-products/

STORAGE GUIDANCE

Please ensure unopened bags are stored in a cool dry area, preferably on a pallet or shelf to keep elevated from the ground and protected from wind and rain.



**FOR UP TO DATE TECHNICAL
ADVICE AND INFORMATION ON
OUR BAGGED PRODUCT RANGE
SCAN THE QR CODE**

